




# Universal bracket IHUB 11884




## SEG 85 701 35



**x1**




Ø28/34, L=35 **x1**



**x1**



**x1**



**x1**



**x1**



M5x8 Pozi **x1**




5,3x15x1,2 fzb **x1**


**A**

**1**


Ø6,5 x 2





**2**



**3**




**4**




**B**


1





2



3



4



**Main office**

Frico AB  
Box 102  
SE-433 22 Partille  
Sweden

Tel: +46 31 336 86 00  
Fax: +46 31 26 28 25  
mailbox@frico.se  
www.frico.se

**For your local contact: [www.frico.se](http://www.frico.se)**